

Transportation Measures Cross-Category & Global Maximum Caps

Cross-Category Maximum- A cross-category maximum is provided for any combination of land use, neighborhood enhancements, parking, and transit strategies (columns A-D in Chart 6-1, with the maximum shown in the top row). The total project VMT reduction across these categories should be capped at these levels based on empirical evidence.¹ Caps are provided for the location/development type of the project. VMT reductions may be multiplied across the four categories up to this maximum. These include:

- Urban: 70% VMT
- Compact Infill: 35%
- Suburban Center (or Suburban with NEV): 15%
- Suburban: 10% (note that projects with this level of reduction must include a diverse land use mix, workforce housing, and project-specific transit; limited empirical evidence is available)

Global Maximum- A global maximum is provided for any combination of land use, neighborhood enhancements, parking, transit, and commute trip reduction strategies (the first five columns in the organization chart). This excludes reductions from road-pricing measurements which are discussed separately below. The total project VMT reduction across these categories, which can be combined through multiplication, should be capped at these levels based on empirical evidence.² Maximums are provided for the location/development type of the project. The Global Maximum values can be found in the top row of Chart 6-2. These include:

- Urban: 75% VMT
- Compact Infill: 40% VMT
- Suburban Center (or Suburban with NEV): 20%
- Suburban: 15% (limited empirical evidence available)

¹ As reported by Holtzclaw, et al for the State of California.

² As reported by Holtzclaw, et al for the State of California. Note that CTR strategies must be converted to overall VMT reductions (from work-trip VMT reductions) before being combined with strategies in other categories.

Transportation Subcategory Rules

Land Use/Location: Land use measures apply to a project area with a radius of ½ mile. If the project area under review is greater than this, the study area should be divided into subareas of radii of ½ mile, with subarea boundaries determined by natural “clusters” of integrated land uses within a common watershed. If the project study area is smaller than ½ mile in radius, other land uses within a ½ mile radius of the key destination point in the study area (i.e. train station or employment center) should be included in design, density, and diversity calculations. Land use measures are capped based on empirical evidence for location setting types as follows:³

- Urban: 65% VMT
- Compact Infill: 30% VMT
- Suburban Center: 10% VMT
- Suburban: 5% VMT


Neighborhood/Site Enhancements: The neighborhood/site enhancements category is capped at 15% VMT reduction (with Neighborhood Electric Vehicles (NEVs)) and 5% without NEVs based on empirical evidence (for NEVs) and the multiplied combination of the non-NEV measures.

Parking: Parking strategies should be implemented in one of two combinations:

- Limited (reduced) off-street supply ratios plus residential permit parking and priced on-street parking (to limit spillover), or
- Unbundled parking plus residential permit parking and priced on-street parking (to limit spillover).

Note: The reduction maximum of 20% VMT reflects the combined (multiplied) effect of unbundled parking and priced on-street parking.

Transit: The 10% VMT reduction maximum for transit system improvements reflects the combined (multiplied) effect of network expansion and service frequency/speed enhancements. A comprehensive transit improvement would receive this type of reduction, as shown in the center overlap in the below Venn diagrams.



³ As reported for California locations in Holtzclaw, et al. “Location Efficiency: Neighborhood and Socioeconomic Characteristics Determine Auto Ownership and Use – Studies in Chicago, Los Angeles, and San Francisco.” *Transportation Planning and Technology*, 2002, Vol. 25, pp. 1–27.

Commuter Trip Reductions (CTR): The most effective commute trip reduction measures combine incentives, disincentives, and mandatory monitoring, often through a transportation demand management (TDM) ordinance. Incentives encourage a particular action, for example parking cash-out, where the employee receives a monetary incentive for not driving to work, but is not punished for maintaining status quo. Disincentives establish a penalty for a status quo action. An example is workplace parking pricing, where the employee is now monetarily penalized for driving to work. The 25% maximum for work-related VMT apply to comprehensive CTR programs. TDM strategies that include only incentives, only disincentives, and/or no mandatory monitoring, should have a lower total VMT reduction than those with a comprehensive approach. Support strategies to strengthen CTR programs include guaranteed-ride-home, taxi vouchers, and message boards/marketing materials. A 25% reduction in work-related VMT is assumed equivalent to a 15% reduction in overall project VMT for the purpose of the global maximum; this can be adjusted for project specific land use mixes.

Two school-related VMT reduction measures are also provided in this category. The maximum reduction for these measures should be 65% of school-related VMT based on the literature.

Road Pricing/Management: Cordon pricing is the only strategy in this category with an expected VMT reduction potential. Other forms of road pricing would be applied at a corridor or region-wide level rather than as mitigation applied to an individual development project. No domestic case studies are available for cordon pricing, but international studies suggest a VMT reduction maximum of 25%. A separate, detailed, and project-specific study should be conducted for any project where road pricing is proposed as a VMT reduction measure.

Additional Rules for Transportation Measures- There are also restrictions on the application of measures in rural applications, and application to baseline, as follows:

Rural Application: Few empirical studies are available to suggest appropriate VMT reduction caps for strategies implemented in rural areas. Strategies likely to have the largest VMT reduction in rural areas include vanpools, telecommute or alternative work schedules, and master planned communities (with design and land use diversity to encourage intra-community travel). NEV networks may also be appropriate for larger scale developments. Because of the limited empirical data in the rural context, project-specific VMT reduction estimates should be calculated.

Baseline Application: As discussed in previous sections of this report, VMT reductions should be applied to a baseline VMT expected for the project, based on the Institute of Transportation Engineers' 8th Edition *Trip Generation Manual* and associated typical trip distance for each land use type. Where trip generation rates and project VMT provided by the project Applicant are derived from another source, the VMT reductions must be adjusted to reflect any "discounts" already applied.