

# Field Evaluation of 2B Technologies Portable Ozone Monitor (PO<sub>3</sub>M)



# Background

- From 07/29/2015 to 09/09/2015, three **2B Technologies Portable Ozone Monitor (PO<sub>3</sub>M)** units were deployed at one of SCAQMD's stationary ambient monitoring sites in Rubidoux and run side-by-side with a Federal Reference Method (FRM) instrument measuring the same pollutant
- 2B Technologies PO<sub>3</sub>M (3 units tested):
  - Gaseous sensors [UV absorption; Federal Equivalent (FEM) Method]
  - Each unit measures: Ozone (ppb)  
Unit cost: ~\$4,500
  - Time resolution: 10-sec to 1-hr
  - Units IDs: 1043, 1105 and 1106
- SCAQMD FRM instrument:
  - Ozone instrument; cost: ~\$7,000
  - Time resolution: 1-min




# Data validation & recovery


- Basic QA/QC procedures were used to validate the collected data (i.e. obvious outliers, negative values and invalid data-points were eliminated from the data-set)
- Data recoveries from units 1043, 1105, and 1106 were 99, 92, and 91%, respectively

## 2B Technologies PO<sub>3</sub>M; intra-model variability




- Low measurement variability was observed between the three PO<sub>3</sub>M units




# 2B Technologies PO<sub>3</sub>M vs FRM (Ozone; 5-min mean)






- Ozone measurements from the three PO<sub>3</sub>Ms show an excellent correlation with the corresponding FRM data ( $R^2 \sim 1.00$ ).




# 2B Technologies PO<sub>3</sub>M vs FRM (Ozone; 1-hr mean)






- Ozone measurements from the three PO<sub>3</sub>M units show an excellent correlation with the corresponding FRM data ( $R^2 \sim 1.00$ ).



# 2B Technologies POM vs FRM (Ozone; 8-hr mean)



- Ozone measurements from the three PO<sub>3</sub>M<sub>s</sub> show an excellent correlation with the corresponding FRM data ( $R^2 \sim 1.00$ ).



# Discussion

- Overall, the three **2B Technologies PO<sub>3</sub>M** Ozone sensors performed very well and showed:
  - Minimal down-time; data recovery from each unit was higher than 90%
  - Very low intra-model variability
- All three PO<sub>3</sub>M units showed excellent correlation with a more expensive FRM instrument ( $R^2 \sim 1.00$ )
- No sensor calibration by AQ-SPEC was performed prior to the beginning of this field testing
- Laboratory chamber testing is necessary to fully evaluate the performance of these sensors under controlled temperature and relative humidity conditions, and in the presence of interfering species such as NO<sub>2</sub>
- These results are still preliminary