Field Evaluation Aeroqual AQY (v0.5)





Background

 From 12/22/2017 to 03/27/2018, three Aeroqual AQY (Version 0.5) multi-sensor units were deployed in Rubidoux and run side-by-side SCAQMD Federal Equivalent Method (FEM) and Federal Reference Method (FRM) instruments measuring the same pollutants

Aeroqual AQY (3 units tested):

- ➤ Sensors: Ozone Gas Sensitive Semiconductor (GSS); NO₂ – Gas Sensitive Electrochemical (GSE) (non-FEM/non-FRM); PM_{2.5} – Laser Particle Counter (LPC) (non-FEM), (model SDS011 by Nova Fitness)
- Each unit measures: O₃ (ppb), NO₂ (ppb), PM_{2.5} (μg/m³), T (degrees C), RH (%)
- ➤ Unit cost: ~\$3,000 (includes 2-yr tech support + cloud data software license)
- ➤ Time resolution: 1-min
- ➤ Units IDs: AQY 130, AQY 131 (AQY 134), AQY 132 (On 2/15/2018, entire unit AQY 131 was replaced by unit AQY 134 due to faulty NO₂ sensor)

SCAQMD Reference instruments:

- ➤ O₃ instrument (FEM); cost: ~\$7,000
 - > Time resolution; 1-min
- ➤ NO_x instrument (FRM); cost: ~\$11,000
 - > Time resolution: 1-min
- ➤ GRIMM (FEM PM_{2.5}); cost: \$25,000 and up
 - > Time resolution: 1-min
- ➤ MetOne BAM (FEM PM_{2.5}); cost: ~\$20,000
 - ➤ Time resolution: 1-hr
- ➤ Met station (T, RH, P, WS, WD); cost: ~\$5,000
 - > Time resolution: 1-min




Ozone (O₃) in AQY


- Basic QA/QC procedures were used to validate the collected data (i.e., obvious outliers, negative values, and invalid data-points were eliminated from the data-set)
- Data recovery for ozone in the four AQYs was high (i.e., 92% for AQY 130; 76% for AQY 131; 97% for AQY 132 and 100% for AQY 134).

Aeroqual AQY; Intra-model variability


 Low measurement variability was observed between the two AQY units (130, 132) for ozone during the entire deployment period.





Aeroqual AQY vs FEM (Ozone; 5-min mean)




- AQY Ozone measurements show an excellent correlation with the corresponding FEM data (R² ~ 0.96)
- The AQYs seem to track well the diurnal ozone variations recorded by the FEM instrument













Aeroqual AQY vs FEM (Ozone; 1-hr mean)




- AQY Ozone measurements show an excellent correlation with the corresponding FEM data (R² ~ 0.96)
- The AQYs seem to track well the diurnal ozone variations recorded by the FEM instrument













Aeroqual AQY vs FEM (Ozone; 8-hr mean)




- AQY Ozone measurements show an excellent correlation with the corresponding FEM data (R² ~ 0.96)
- The AQYs seem to track well the diurnal ozone variations recorded by the FEM instrument









Nitrogen Dioxide (NO₂) in AQY

NO₂ Data Handling

During this AQ-SPEC field evaluation, Aeroqual corrected and calculated NO₂ in all four units, using two different approaches:

1st approach (in this report, pollutant referred to as NO₂):

- NO₂ with correction for O₃ bias using AQY ozone data in real-time
- Calculation by on-instrument Aeroqual algorithm

2nd approach (in this report, pollutant referred to as NO₂ V2)

- NO₂ with correction for O₃ and RH bias using AQY ozone and AQY RH data in real-time
- Calculation by <u>new</u> on-instrument Aeroqual algorithm

To better assist in understanding the procedures mentioned above, Aeroqual has shared all related proprietary information with AQ-SPEC


- Basic QA/QC procedures were used to validate the collected data (i.e., obvious outliers, negative values, and invalid data-points were eliminated from the data-set)
- Data recovery for NO₂ in the four AQYs was high (i.e., 98% for AQY 130; 95% for AQY 131; 85% for AQY 132 and 92% for AQY 134).

Aeroqual AQY; Intra-model variability


 Substantial measurement variability was observed between the two AQY units (130, 132) for nitrogen dioxide during the entire deployment period.





Aeroqual AQY vs FRM (NO₂; 5-min mean)




- AQY NO₂ measurements show a moderate correlation with the corresponding FRM data (R² ~ 0.50)
- The AQYs seem to track the diurnal NO₂ variations recorded by the FRM instrument











- Basic QA/QC procedures were used to validate the collected data (i.e., obvious outliers, negative values, and invalid data-points were eliminated from the data-set)
- Data recovery for NO₂ V2 in the four AQYs was high (i.e., 98% for AQY 130; 99% for AQY 131; 97% for AQY 132 and 99% for AQY 134).

Aeroqual AQY; Intra-model variability


 Very low measurement variability was observed between the two AQY units (130, 132) for nitrogen dioxide (V2) during the entire deployment period.





Aeroqual AQY vs FRM (NO₂; 5-min mean)




- AQY NO₂ measurements in AQYs 130 and 132 correlate well with the corresponding FRM data (R² ~ 0.77)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal NO₂ variations recorded by the FRM instrument













Aeroqual AQY vs FRM (NO₂; 1-hr mean)




- AQY NO₂ measurements in AQYs 130 and 132 correlate well with the corresponding FRM data (R² ~ 0.79)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal NO₂ variations recorded by the FRM instrument













Aeroqual AQY vs FRM (NO₂; 24-hr mean)




- AQY NO₂ measurements in AQYs 130 and 132 correlate very well with the corresponding FRM data (R² ~ 0.83)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal NO₂ variations recorded by the FRM instrument












- Basic QA/QC procedures were used to validate the collected data (i.e., obvious outliers, negative values, and invalid data-points were eliminated from the data-set)
- AQY PM_{2.5} was corrected based on AQY RH data in real-time
- Data recovery for PM_{2.5} in the four AQYs was excellent (i.e., 99% for AQY 130; 100% for AQY 131, AQY 132 and AQY 134).

Aeroqual AQY; Intra-model variability


Very low measurement variability was observed between the two AQY units (130, 132) for PM_{2.5} during the entire deployment period.




- Basic QA/QC procedures were used to validate the collected FEM data (i.e. obvious outliers, negative values and invalid data-points were eliminated from data-set)
- PM_{2.5} data recovery was 68 % for the GRIMM and 88 % for the BAM.


Equivalent methods: BAM vs GRIMM

Excellent agreement between the two equivalent methods for PM_{2.5}








Aeroqual AQY vs FEM (GRIMM PM_{2.5}; 5-min mean)




- AQY PM_{2.5} measurements in AQYs 130 and 132 correlate very well with the corresponding FEM GRIMM data (R² ~ 0.86)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track well the diurnal PM_{2.5} variations recorded by the FEM GRIMM instrument













Aeroqual AQY vs FEM (GRIMM PM_{2.5}; 1-hr mean)




- AQY PM_{2.5} measurements in AQYs 130 and 132 correlate very well with the corresponding FEM GRIMM data (R² ~ 0.86)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track well the diurnal PM_{2.5} variations recorded by the FEM GRIMM instrument













Aeroqual AQY vs FEM (GRIMM PM_{2.5}; 24-hr mean)




- AQY PM_{2.5} measurements in AQYs 130 and 132 correlate very well with the corresponding FEM GRIMM data (R² ~ 0.92)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track well the diurnal PM_{2.5} variations recorded by the FEM GRIMM instrument













Aeroqual AQY vs FEM (BAM PM_{2.5}; 1-hr mean)




- AQY PM_{2.5} measurements in AQYs 130 and 132 correlate very well with the corresponding FEM BAM data (R² ~ 0.84)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal PM_{2.5} variations recorded by the FEM BAM instrument













Aeroqual AQY vs FEM (BAM PM_{2.5}; 24-hr mean)




- AQY PM_{2.5} measurements in AQYs 130 and 132 correlate very well with the corresponding FEM BAM data (R² ~ 0.90)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal PM_{2.5} variations recorded by the FEM BAM instrument













Aeroqual AQY vs SCAQMD Met Station (Temp; 5-min mean)




- AQY Temp measurements in AQYs 130 and 132 correlate very well with the corresponding SCAQMD Met Station sensor (R² ~ 0.93)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal Temp variations recorded by the SCAQMD Met station sensor












Aeroqual AQY vs SCAQMD Met Station (RH; 5-min mean)





On 2/15/18, AQY 131 was replaced by AQY 134

- AQY RH measurements in AQYs 130 and 132 correlate very well with the corresponding SCAQMD Met Station sensor (R² ~ 0.96)
- The two AQYs seem to be highly accurate
- The two AQYs seem to track the diurnal RH variations recorded by the SCAQMD Met station sensor









Discussion

- With the exception of a faulty NO₂ sensor in one of the three units (AQY 131), the Aeroqual AQY v0.5 multi-sensor units (AQY 130 and 132) performed very well and showed:
 - ➤ Minimal down-time: data recovery from each unit was higher than 90%
 - ➤ Low intra-model variability for all measured pollutants
- During the <u>entire</u> field deployment testing period:
 - Ozone sensors showed excellent correlation with a more expensive FEM instrument (R² > 0.95)
 - $ightharpoonup NO_2$ V2 sensors showed very good correlation with a more expensive FRM instrument (R² > 0.74) and high accuracy
 - $ightharpoonup PM_{2.5}$ sensors showed very good correlation with more expensive FEM instruments (GRIMM: $R^2 > 0.84$ and BAM: $R^2 > 0.83$) and high accuracy
 - ➤ Temperature and relative humidity sensors showed excellent correlation with the SCAQMD Met Station sensors (T: R² > 0.91 and RH: R² > 0.94)
- No sensor calibration was performed by AQ-SPEC prior to the beginning of this field testing
- Laboratory chamber testing is necessary to fully evaluate the performance of these sensors under controlled T and RH conditions, and known target and interferent pollutants concentrations.
- These results are still preliminary