

Laboratory Evaluation

Alphasense OPC-N2 PM Sensor



Background

Three **Alphasense OPC-N2** (units IDs: 216, 222, 308) were field-tested at the SCAQMD Rubidoux fixed ambient monitoring station (07/10/2015 to 08/10/2015) under ambient weather conditions. Now, three new OPC-N2 (units ID: 0508, 1202, 1207) have been evaluated in the SCAQMD Chemistry Laboratory under controlled PM concentration, temperature, and relative humidity.

OPC-N2 PMS1003 (3 units tested):

- Particle sensors (**optical; non-FEM**)
- Each unit measures: $PM_{1.0}$, $PM_{2.5}$, PM_{10} mass concentration ($\mu g/m^3$)
- **Unit cost: ~\$450**
- Time resolution: 1.4 to 20 seconds
- Units IDs: 0508, 1202, 1207



GRIMM EDM 180 (ref. method for $PM_{1.0}$, $PM_{2.5}$ mass):



- Optical particle counter
- **FEM $PM_{2.5}$**
- Uses proprietary algorithms to calculate total PM, $PM_{2.5}$, and $PM_{1.0}$ mass conc. from particle number measurements
- **Cost: ~\$25,000**

TSI APS 3321 (ref. method for PM_{10} mass):

- Aerodynamic particle sizer
- Measures particles from 0.5 to 20 μm
- Uses a patented, double-crest optical system for unmatched sizing accuracy
- **Cost: ~\$50,000**

Evaluation results guideline


- OPC-N2 v.s. GRIMM PM_{1.0} mass concentration
- OPC-N2 v.s. GRIMM PM_{2.5} mass concentration
- OPC-N2 v.s. APS v.s. GRIMM PM₁₀ mass concentration



Evaluation results for OPC-N2 PM_{1.0} mass


OPC-N2 vs GRIMM

Coefficient of Determination: OPC-N2 PM_{1.0} vs GRIMM



- Over the full PM_{1.0} concentration range tested (0-230 µg/m³), OPC-N2 units 0508 and 1207 tracked well the diurnal variations as recorded by the GRIMM.
- For this experiment, Unit 1202 did not record valid measurements. Later, Unit 1202 resumed normal data logging by itself.

Linearity of Unit Response



- OPC-N2 units 0508 and 1207 showed excellent correlation with GRIMM PM_{1.0} measurement data ($R^2 = 0.99$) between 0-230 µg/m³.
- The OPC-N2 units overestimated the GRIMM PM_{1.0} concentration.

OPC-N2 PM_{1.0} Accuracy

- Accuracy (20 °C and 40% RH)

Steady State (#)	Sensor mean (µg/m ³)	GRIMM (µg/m ³)	Accuracy (%)
1	25.6	13.7	13.4
2	70.6	35.3	0.3
3	125.2	67.2	13.8
4	262.8	153.9	29.2
5	360.2	230.7	43.8




- The OPC-N2 units showed low to moderate accuracy levels compared to GRIMM PM_{1.0} over the concentration range of 0-230 µg/m³. Accuracy ranged from 0.3% to 43.8%. In general, OPC-N2 units overestimated the PM_{1.0} mass measured by GRIMM.

OPC-N2 PM_{1.0} Data Recovery & Intra-model Variability

- Data recovery for PM_{1.0} mass concentration from 0508, 1202, and 1207 was 100%, 42.4%, and 100%.
- Low PM_{1.0} measurement variations were observed between the units 0508 and 1207. Unit 1202 did not record valid data during the intra-model variability test.

OPC-N2 PM_{1.0} Precision


- Precision (%), Effect of PM_{1.0} conc., temperature and relative humidity)




- Overall, the OPC-N2 units showed high precision for most of T, RH, and PM conc. combinations, except for very high humidity conditions at 5, and 20 °C.
- GRIMM's precision was high across all conditions.

*100% represents high precision.

OPC-N2 PM_{1.0} Climate Susceptibility



Low Temp – RH ramping
(medium conc.)




High Temp – RH ramping
(medium conc.)

Evaluation results for OPC-N2 PM_{2.5} mass


OPC-N2 vs GRIMM

Coefficient of Determination: OPC-N2 PM_{2.5} vs FEM GRIMM



- Over the full PM_{2.5} concentration range tested (0-300 µg/m³), OPC-N2 units 0508 and 1207 tracked well the diurnal variations as recorded by the FEM GRIMM.
- For this experiment, Unit 1202 did not record valid measurements. Later, Unit 1202 resumed normal data logging by itself.

Linearity of Unit Response



- OPC-N2 units 0508 and 1207 showed excellent correlation with FEM GRIMM PM_{1.0} measurement data ($R^2 = 0.99$) between 0-300 µg/m³.
- The OPC-N2 units overestimated the FEM GRIMM PM_{2.5} mass concentration.

OPC-N2 PM_{2.5} Accuracy

- Accuracy (20 °C and 40% RH)

Steady State (#)	Sensor mean ($\mu\text{g}/\text{m}^3$)	FEM ($\mu\text{g}/\text{m}^3$)	Accuracy (%)
1	32.6	16.0	-3.9
2	93.0	39.9	-33.2
3	171.8	77.8	-20.9
4	382.6	193.3	2.1
5	545.8	299.5	17.8


- The OPC-N2 units showed low accuracy compared to FEM GRIMM PM_{2.5} over the concentration range tested (0-300 $\mu\text{g}/\text{m}^3$). Accuracy varied from -33.2% to 17.8%. At low to medium PM_{2.5} concentrations, the sensors overestimated the FEM GRIMM by more than 100%, therefore, the calculated accuracy generated negative values.

OPC-N2 PM_{2.5} Data Recovery & Intra-model Variability

- Data recovery for PM_{2.5} mass concentration from 0508, 1202, and 1207 was 100%, 42.4%, and 100%.
- Low PM_{2.5} measurement variations were observed between the units 0508 and 1207. Unit 1202 did not record valid data during the intra-model variability test.

OPC-N2 PM_{2.5} Precision


- Precision (%), Effect of PM_{2.5} conc., temperature and relative humidity)




- Overall, the OPC-N2 units showed high precision for most of T, RH, and PM conc. combinations, except for high humidity levels at 5 °C, and also at 5 °C/15% RH.
- FEM GRIMM's precision was also high across all conditions.

*100% represents high precision.

OPC-N2 PM_{2.5} Climate Susceptibility



Low Temp – RH ramping
(medium conc.)



High Temp – RH ramping
(medium conc.)


Discussion

- **Accuracy:** Overall, the OPC-N2 units have low accuracy, compared to the GRIMM PM_{1.0} and PM_{2.5} in the tested range. The OPC-N2 units overestimated the PM_{1.0} and PM_{2.5} mass measured by GRIMM. (refer to slide 6 and 11).
- **Precision:** The OPC-N2 units have high precision for most of tested combinations (PM concentrations, T and RH), except at high humidity levels at 5 °C. (refer to slide 7 and 12)
- **Intra-model variability:** Low intra-model variability was observed between units 0508 and 1207. Unit 1202 had significant data loss, and did not record valid data during the intra-model variability experiment.
- **Data Recovery:** Data recovery from 0508, 1202, and 1207 was 100%, 42.4%, and 100%. Unit 1202 did not record valid data for a period of time, but later it resumed normal performance on its own.
- **Linearity of sensor response:** OPC-N2 units showed excellent correlation/linear response with the corresponding GRIMM PM_{1.0} and PM_{2.5} measurement data ($R^2 = 0.99$ and 0.99 , respectively) for mass concentration range between 0 and 300 $\mu\text{g}/\text{m}^3$. (refer to slides 5 and 10)
- **Climate susceptibility:** From the laboratory studies, low temperature and high humidity affected the precision of OPC-N2 units. (refer to slide 7 and 12)

Evaluation results for OPC-N2 PM₁₀ mass



OPC-N2 vs APS vs GRIMM

Coefficient of Determination: OPC-N2 PM₁₀ vs GRIMM vs APS



- Over the full PM₁₀ concentration range tested (0-200 µg/m³), the OPC-N2 units tracked well the diurnal variations as recorded by the APS and GRIMM.

Linearity of Unit Response



OPC-N2 vs APS: Accuracy

- Accuracy* (20 °C and 40% RH)

Steady State (#)	Sensor mean ($\mu\text{g}/\text{m}^3$)	APS-2.6 ($\mu\text{g}/\text{m}^3$)	Accuracy (%)
1	18.7	21.3	86.3
2	22.0	25.3	85.1
3	46.5	51.6	89.1
4	109.3	116.3	93.6
5	172.5	179.6	95.9


- The OPC-N2 units had high accuracy when compared to APS. The units' accuracy ranges from 85.1% to 95.9%.

OPC-N2 PM₁₀ Data Recovery & Intra-model Variability

- Data recovery for PM₁₀ mass concentration from 0508, 1202, and 1207 was 96.8%, 9.5%, and 96.8%.
- Low PM₁₀ measurement variations were observed between the units 0508 and 1207. Unit 1202 did not record valid data during the intra-model variability test.


OPC-N2 PM₁₀ Climate Susceptibility

OPC-N2 vs APS vs GRIMM (RH ramping, med PM₁₀ mass and 5 °C)



Low Temp – RH ramping
(medium conc.)

OPC-N2 vs APS vs GRIMM (RH ramping, med PM₁₀ mass and 35 °C)



High Temp – RH ramping
(medium conc.)

Discussion

- **Accuracy:** The OPC-N2 units had high accuracy when compared to APS. The units' accuracy ranges from 85.1% to 95.9%. (refer to slide 17)
- **Precision:** Due to the nature of Arizona test dust, the aerosol concentration showed some variability in the chamber, therefore, the precision could not be estimated. At high humidity levels at 5 °C the OPC-N2 units recorded out of range PM₁₀ concentrations in thousands of micrograms per cubic meter. (refer to slide 18)
- **Intra-model variability:** Low intra-model variability was observed between units 0508 and 1207. Unit 1202 had significant data loss, and did not record valid data during the intra-model variability experiment.
- **Data Recovery:** Data recovery for PM₁₀ mass concentration from 0508, 1202, and 1207 were 96.8%, 9.5%, and 96.8%.
- **Linearity of sensor response:** OPC-N2 units showed excellent correlation/linear response with the corresponding APS PM₁₀ ($R^2 = 0.99$) and GRIMM PM₁₀ ($R^2 = 0.99$). (refer to slide 16)
- **Climate susceptibility:** At low temperature and high humidity levels, the OPC-N2 units recorded out of range PM₁₀ mass concentrations.