

# Laboratory Evaluation

## PurpleAir PA-II PM Sensor



# Background

Three **PurpleAir PA-II** sensors that were previously evaluated for their performance in the field (deployment period: 12/08/2016 to 01/26/2017) under ambient environmental conditions, have now been evaluated in the SCAQMD Chemistry Laboratory under controlled artificial aerosol concentration/size range, temperature, and relative humidity.

## PurpleAir PA-II (3 nodes tested):

- Particle sensors (**optical; non-FEM**) (model PMS 5003; *two identical sensors per node*)
- Each sensor reports:  $PM_1$ ,  $PM_{2.5}$ ,  $PM_{10}$  mass concentration ( $\mu\text{g}/\text{m}^3$ )
- Time resolution: 35-sec
- **Unit cost: ~\$200**
- Units IDs: Node #1 (8464a, 8464b); Node #2 (cc53a, cc53b); Node #3 (d688a, d688b)

## GRIMM (ref. method for $PM_1$ and $PM_{2.5}$ mass):


- Optical particle counter
- **FEM  $PM_{2.5}$**
- Uses proprietary algorithms to calculate  $PM_{10}$ ,  $PM_{2.5}$ , and  $PM_1$  mass conc. from particle number measurements
- **Cost: ~\$25,000**

## TSI APS 3321 (ref. method for $PM_{10}$ mass):

- Aerodynamic particle sizer
- Measures particles from 0.5 to 20  $\mu\text{m}$
- Uses a patented, double-crest optical system for unmatched sizing accuracy
- **Cost: ~\$50,000**

# Evaluation results guideline


- PurpleAir PA-II vs GRIMM PM<sub>1</sub> mass concentration
- PurpleAir PA-II vs GRIMM PM<sub>2.5</sub> mass concentration
- PurpleAir PA-II vs APS vs GRIMM PM<sub>10</sub> mass concentration



# Evaluation results for PurpleAir PA-II PM<sub>1</sub> mass concentration


PurpleAir PA-II vs GRIMM

# sensor a vs b comparison




- Each PurpleAir PA-II nodes contains two identical raw sensors, denoted *a* and *b*. For a PM concentration ramping experiment, sensor *b* had excellent linear correlation with  $R^2 > 0.99$ .
- However, sensor *b* reported 10-33% higher PM<sub>1</sub> mass concentration than sensor *a* did.
- In order to strictly follow the AQ-SPEC laboratory evaluation protocol, only data from the three *a* sensors is considered in determining evaluation parameters.

# PA-II vs GRIMM (PM<sub>1</sub> mass; 5-min mean)



- Over the full PM<sub>1</sub> concentration range tested (0-175  $\mu\text{g}/\text{m}^3$ ), the three PA-II sensors tracked well with the concentration variation recorded by GRIMM.

## Coefficient of Determination



- PA-II sensors showed excellent linear correlation with GRIMM PM<sub>1</sub> mass conc. ( $R^2 > 0.99$ ) between 0-175  $\mu\text{g}/\text{m}^3$ .
- PA-II sensors underestimated the GRIMM PM<sub>1</sub> mass conc.

# PM<sub>1</sub> Accuracy: PA-II vs GRIMM

- Accuracy (20 °C and 40% RH)

Steady State (#)	Sensor mean (µg/m <sup>3</sup> )	GRIMM (µg/m <sup>3</sup> )	Accuracy (%)
1	12.6	11.0	85.2
2	29.0	30.7	94.5
3	53.0	69.8	76.0
4	87.9	120.8	72.7
5	120.5	172.6	69.8

- The PurpleAir PA-II sensors showed good accuracy compared to GRIMM PM<sub>1</sub> over the concentration range of 0-175 µg/m<sup>3</sup> at 20 °C and 40% RH. PA-II sensors had better accuracy (85-95%) at lower PM<sub>1</sub> concentration (10-30 µg/m<sup>3</sup>). PurpleAir PA-II sensors' accuracy decreased to ~70% when PM<sub>1</sub> mass conc. was between 70-175 µg/m<sup>3</sup>.


## PA-II Data Recovery and Intra-model variability

- Data recovery for PM<sub>1</sub> mass concentration from 8464a, cc53a, and b688a were 95.9%, 96.6%, and 96.7%.
- Low PM<sub>1</sub> measurement variations were observed among the three PA-II units.


# PM<sub>1</sub> Precision: PurpleAir PA-II

- Precision (Effect of PM<sub>1</sub> conc., Temperature and Relative Humidity)


Low conc.



Medium conc.




High conc.




- Overall, the three PA-II sensors showed high precision for most of the combinations of low, medium and high PM<sub>1</sub> conc., T, and RH.
- At low PM<sub>1</sub> mass conc. and 5 °C/15% RH, precision was lower for both the sensors and the GRIMM.



# PurpleAir PA-II Climate Susceptibility



Low Temp - RH ramping  
(medium conc.)




High Temp - RH ramping  
(medium conc.)

# Evaluation results for PurpleAir PA-II PM<sub>2.5</sub> mass concentration


PurpleAir PA-II vs FEM GRIMM

# sensor a vs b comparison




- PurpleAir PA-II contains two raw sensors in each unit, denoted *a* and *b*. For a PM concentration ramping experiment, sensor *a* and sensor *b* had excellent linear correlation with  $R^2 > 0.99$ .
- However, sensor *b* reported 11-37% higher PM<sub>2.5</sub> mass concentration than sensor *a* did.
- In order to strictly follow the AQ-SPEC laboratory evaluation protocol, only data from the three *a* sensors is considered in determining evaluation parameters.

# PA-II vs FEM GRIMM (PM<sub>2.5</sub> mass; 5-min mean)



- Over the full PM<sub>2.5</sub> concentration range tested (0-250  $\mu\text{g}/\text{m}^3$ ), the three PA-II sensors tracked well with the concentration variation recorded by FEM GRIMM.

## Coefficient of Determination



- Three PA-II sensors showed excellent correlation with GRIMM PM<sub>2.5</sub> mass conc. ( $R^2 > 0.99$ ) between 0-250  $\mu\text{g}/\text{m}^3$ .
- PA-II sensor underestimated the GRIMM PM<sub>2.5</sub> mass conc.

# PM<sub>2.5</sub> Accuracy: PA-II vs FEM GRIMM

- Accuracy (20 °C and 40% RH)

Steady State (#)	Sensor mean (µg/m <sup>3</sup> )	GRIMM (µg/m <sup>3</sup> )	Accuracy (%)
1	19.7	13.5	54.3
2	44.3	35.7	75.7
3	80.8	84.1	96.1
4	134.7	155.1	86.8
5	186.3	233.5	79.8

- The three PA-II sensors showed moderate to good accuracy (54.3-96.1%) compared to FEM GRIMM PM<sub>2.5</sub> over the concentration range tested (0-250 µg/m<sup>3</sup>).


## PA-II Data Recovery and Intra-model variability

- Data recovery for PM<sub>2.5</sub> mass concentration from 8464a, cc53a, and b688a were 96.1%, 96.6%, and 96.1%.
- Low PM<sub>2.5</sub> measurement variations were observed among the three PA-II sensors.


# PM<sub>2.5</sub> Precision: PurpleAir PA-II

- Precision (Effect of PM<sub>2.5</sub> conc., Temperature and Relative Humidity)


Low conc.



Medium conc.




High conc.




- Overall, the three PA-II sensors showed high precision for most of the combinations of low, medium and high PM<sub>2.5</sub> conc., T, and RH.
- At 5 °C/15% RH, 5 °C/40% and low PM<sub>2.5</sub> mass conc., precision was lower for both the sensors and the GRIMM.

# PurpleAir PA-II Climate Susceptibility



Low Temp - RH ramping  
(medium conc.)



High Temp - RH ramping  
(medium conc.)

# Discussion (PM<sub>1</sub> and PM<sub>2.5</sub>)


- **Accuracy:** Overall, the three PA-II sensors have moderate to good accuracy, compared to GRIMM PM<sub>1</sub> and PM<sub>2.5</sub> in the range of 0 to 250 µg/m<sup>3</sup>.
- **Precision:** The three PA-II sensors have high precision for most of the test combinations (PM concentrations, T and RH).
- **Intra-model variability:** Low intra-model variability was observed among the three PA-II sensors.
- **Data Recovery:** Data recovery for PM<sub>1</sub> mass concentration from 8464a, cc53a, and b688a was 95.9%, 96.6%, and 96.7%. Data recovery for PM<sub>2.5</sub> mass concentration from 8464a, cc53a, and b688a was 96.1%, 96.6%, and 96.6%.
- **Linear correlation:** The three PA-II sensors showed very good correlation/linear response with the corresponding GRIMM PM<sub>1</sub> and PM<sub>2.5</sub> measurement data ( $R^2 > 0.99$ ) for mass concentration range between 0 and 250 µg/m<sup>3</sup>.
- **Climate susceptibility:** For most of the temperature and relative humidity combinations, the climate condition had minimal effect on the PA-II's precision. At the set-points of RH changes at low PM concentrations, PA-II sensors had some spikes.





# Evaluation results for PurpleAir PA-II PM<sub>10</sub> mass concentration

PurpleAir PA-II vs GRIMM vs APS

# PA-II vs APS vs GRIMM (PM<sub>10</sub> mass; 5-min mean) Concentration ramping at 20 °C, 40% RH



- Over the full PM<sub>10</sub> concentration range tested (0-200 µg/m<sup>3</sup> as measured by APS using 2.6 g/cm<sup>3</sup>), the three PA-II sensors tracked well the conc. variation as recorded by the APS and GRIMM.
- The PA-II sensors underestimated the PM<sub>10</sub> mass concentration measured by APS and GRIMM, especially at higher concentration.



# PM<sub>10</sub> Accuracy: PA-II vs APS vs GRIMM

- Accuracy (20 °C and 40% RH)


Steady State (#)	Sensor mean (µg/m <sup>3</sup> )	APS-2.6 (µg/m <sup>3</sup> )	Accuracy (%)	Steady State (#)	Sensor mean (µg/m <sup>3</sup> )	GRIMM (µg/m <sup>3</sup> )	Accuracy (%)
1	13.8	21.4	64.5	1	13.8	19.0	72.7
2	21.7	31.8	68.3	2	21.7	30.0	72.2
3	41.8	60.4	69.2	3	41.8	60.4	69.3
4	63.3	120.9	52.4	4	63.3	120.3	52.7
5	78.8	178.7	44.1	5	78.8	188.0	41.9

- The three PA-II sensors had moderate accuracy (44%-73%) when compared to APS and GRIMM. As PM<sub>10</sub> concentration increased, sensors' accuracy decreased. Sensors underestimated PM<sub>10</sub> concentration as measured by APS and GRIMM.


## PA-II Data Recovery and Intra-model variability

- Data recovery for PM<sub>10</sub> mass concentration from 8464a, cc53a, and b688a were 94.4%, 93.2%, and 94.0%.
- Low PM<sub>10</sub> measurement variations were observed among the three PA-II sensors.

# PurpleAir PA-II Climate Susceptibility



Low Temp - RH ramping  
(medium conc.)



High Temp - RH ramping  
(medium conc.)

# Discussion (PM<sub>10</sub>)

- **Accuracy:** The three PA-II sensors had moderate accuracy (44%-73%) when compared to APS and GRIMM. As PM<sub>10</sub> concentration increased, sensors' accuracy decreased. Sensors underestimated PM<sub>10</sub> concentration as measured by APS and GRIMM.
- **Precision:** Due to the nature of Arizona test dust, the aerosol concentration showed some variability, therefore, the precision cannot be fairly estimated. As observed in the climate susceptibility experiments, APS and GRIMM showed higher sensitivity to the aerosol concentration changes than the three PA-II sensors did.
- **Intra-model variability:** Low intra-model variability was observed among the PA-II sensors.
- **Data Recovery:** Data recovery for PM<sub>10</sub> mass concentration from 8464a, cc53a, and b688a were 94.4%, 93.2%, and 94.0%.
- **Linearity of sensor response:** PA-II sensors showed good correlation/linear response with the corresponding APS PM<sub>10</sub> ( $R^2 = 0.95$ ) and GRIMM PM<sub>10</sub> ( $R^2 = 0.94$ ).
- **Climate susceptibility:** From the laboratory studies, temperature and relative humidity had minimal effect on the PA-II sensors' performance. At the set-points of RH changes, units reported spiked changes in concentrations.