

# AQ-SPEC

## Air Quality Sensor Performance Evaluation Center

### Sensor Description

Manufacturer/Model:  
Purple Air PA-I

Pollutants:  
PM<sub>1.0</sub>, PM<sub>2.5</sub>, PM<sub>10</sub>

Measurement Range:  
0 - 500 µg/m<sup>3</sup>

Type: Optical



### Additional Information

#### Field evaluation report:

<http://www.aqmd.gov/aq-spec/evaluations/field>

#### Lab evaluation report:

<http://www.aqmd.gov/aq-spec/evaluations/laboratory>

#### AQ-SPEC website:



<http://www.aqmd.gov/aq-spec>

### Evaluation Summary

- Overall, the three Purple Air PA-I sensors showed low accuracy, compared to the reference instrument for PM<sub>1.0</sub>, PM<sub>2.5</sub>, and PM<sub>10</sub>, for a concentration range between 0 to 320 µg/m<sup>3</sup>.
- The three PA-I sensors exhibited high precision during all tested environmental conditions.
- PA-I sensors showed low intra-model variability as well as good data recovery (99.9%).
- For PM<sub>1.0</sub> and PM<sub>2.5</sub>, the PA-I sensors had high correlation with the reference instrument from both the field (PM<sub>1.0</sub> R<sup>2</sup> > 0.85, PM<sub>2.5</sub> R<sup>2</sup> > 0.90) and laboratory studies (linear correlation PM<sub>1.0</sub> R<sup>2</sup> > 0.95, PM<sub>2.5</sub> R<sup>2</sup> > 0.99). For PM<sub>10</sub>, the PA-I sensors did not always follow the concentration change recorded by FEM instrument in the field (PM<sub>10</sub> R<sup>2</sup> > 0.39), however in the laboratory, the PA-I sensors followed the concentration ramping (increasing) change, reporting (PM<sub>10</sub> R<sup>2</sup> > 0.97).

### Field Evaluation Highlights

- Deployment period 02/19/2016- 04/19/2016: the three PA-I sensors correlated well the PM<sub>1.0</sub>, PM<sub>2.5</sub> concentration change as monitored by FEM instrument. PA-I sensors did not always follow the FEM PM<sub>10</sub> concentration change.
- The units showed 99.9% data recovery as well as low intra-model variability.



PM<sub>1.0</sub> R<sup>2</sup> > 0.85

PM<sub>10</sub> R<sup>2</sup> > 0.39

Correlation coefficient (R<sup>2</sup>) quantifies how the three sensors followed the ozone concentration change by FEM.

An R<sup>2</sup> approaching the value of 1 reflects a near perfect agreement, whereas a value of 0 indicates a complete lack of correlation.

# Laboratory Evaluation Highlights


## Accuracy

$$A (\%) = 100 - \frac{|\bar{X} - \bar{R}|}{\bar{R}} * 100$$


Accuracy was evaluated in a concentration ramping experiment at 20 °C and 40%. The sensor's readings at each ramping steady state were compared to the reference instrument.

Negative % means sensors' overestimation. The higher the positive value (close to 100%), the higher the sensor's accuracy.

Steady State (#)	Sensor PM <sub>2.5</sub> (µg/m <sup>3</sup> )	FEM PM <sub>2.5</sub> (µg/m <sup>3</sup> )	Accuracy (%)
1	43.8	15.9	-74.8
2	96.5	33.4	-88.6
3	187.0	62.4	-99.7
4	505.4	167.6	-101.6
5	796.2	282.6	-81.7
6	866.9	322.1	-69.1




## Precision (PM<sub>2.5</sub>)



Sensor's ability of generating precise measurements of PM concentration at low, medium, and high pollutant levels were evaluated under 9 combinations of T and RH, including extreme weather conditions like cold and humid (5 °C and 65%), hot and humid (35 °C and 65%), cold and dry (5 °C and 15%), and hot and dry (35 °C and 15%).

## Linear Correlation Coefficient



The three PA-I sensors showed excellent correlation with the corresponding FEM PM<sub>2.5</sub> data ( $R^2 = 0.99$ ) at 20 °C and 40% RH.

For conc. ramping experiments of PM<sub>1.0</sub> and PM<sub>10</sub>, please see full length lab reports.

## Climate Susceptibility

From the laboratory studies, temperature and relative humidity had minimal effect on the Purple Air PA-I units' precision in most cases. At the set-points of RH changes, PA-I reported spiked changes in concentrations.

## Observed Interferents

Not tested for PM sensors



All documents, reports, data, and other information provided in this document are for informational use only. Mention of trade names or commercial products does not constitute endorsement or recommendation. The South Coast AQMD's AQ-SPEC program, as a government agency, recommends the interested parties to make purchase decisions based on their application.