

# Laboratory Evaluation

## IQAir AirVisual Pro PM<sub>2.5</sub> Sensor




# Background

Three **IAQAir AirVisual Pro PM<sub>2.5</sub>** sensors (units IDs: 4VW9, WLL6, and X44P), previously field tested at the SCAQMD Rubidoux fixed ambient monitoring station (08/02/2017 to 10/05/2017) under ambient environmental conditions, have now been evaluated in the SCAQMD Chemistry Laboratory under controlled artificial aerosol concentration/size range, temperature, and relative humidity conditions.

## **IAQAir AirVisual Pro Sensor (3 units tested):**

- PM<sub>2.5</sub> (μg/m<sup>3</sup>) (**optical; non-FEM**)
- PM<sub>10</sub> (μg/m<sup>3</sup>) (**optical; non-FEM**)
- CO<sub>2</sub> (ppm)
- VOC (ppb)
- **Unit cost: \$269 USD**
- Time resolution: 10 seconds
- Units IDs: 4VW9, WLL6, X44P




IAQAir AirVisual Pro

## **GRIMM (reference method):**


- Optical particle counter
- **FEM PM<sub>2.5</sub>**
- Uses proprietary algorithms to calculate total PM, PM<sub>2.5</sub>, and PM<sub>1</sub> mass conc. from particle number measurements
- **Cost: ~\$25,000**
- Time resolution: 1-min



# IQAir AirVisual Pro vs FEM GRIMM (PM<sub>2.5</sub> mass; 5-min mean)



- The three IQAir AirVisual Pro tracked well with the concentration variation recorded by FEM GRIMM in the concentration range of 0-250  $\mu\text{g}/\text{m}^3$ .



- Three IQAir AirVisual Pro sensors showed excellent correlation with GRIMM PM<sub>2.5</sub> mass conc. ( $R^2 > 0.99$ ).
- IQAir AirVisual Pro sensors overestimated the GRIMM PM<sub>2.5</sub> mass conc.;, with a slope of 0.53.

# PM<sub>2.5</sub> Accuracy: IQAir AirVisual Pro vs. GRIMM

- Accuracy (20 °C and 40% RH)

Steady State (#)	Sensor mean ( $\mu\text{g}/\text{m}^3$ )	GRIMM ( $\mu\text{g}/\text{m}^3$ )	Accuracy (%)
1	21.3	10.9	5.2
2	69.0	33.5	-6.2
3	154.6	79.3	5.0
4	288.6	153.0	11.4
5	440.0	228.5	7.4

- The three IQAir AirVisual Pro sensors overestimated FEM GRIMM PM<sub>2.5</sub> mass concentration over the concentration range of 0-250  $\mu\text{g}/\text{m}^3$ . Therefore, according to the calculation below, IQAir AirVisual Pro sensors have low accuracy compared to FEM GRIMM.


## IQAir AirVisual Pro Data Recovery and Intra-model variability

- Data recovery for PM<sub>2.5</sub> mass concentration from Unit 4VW9, Unit WLL6, and Unit X44P was 100%.
- Low PM<sub>2.5</sub> measurement variations were observed among the three IQAir AirVisual Pro units.


# PM<sub>2.5</sub> Precision: IQAir AirVisual Pro

- Precision (Effect of PM<sub>2.5</sub> conc., Temperature and Relative Humidity)


Low conc.



Medium conc.




High conc.




- Overall, the three IQAir AirVisual Pro sensors showed high precision for all combinations of low, medium and high PM<sub>2.5</sub> conc., T, and RH over a FEM GRIMM PM<sub>2.5</sub> conc. range of 0-250 µg/m<sup>3</sup>.

# IQAir AirVisual Pro Climate Susceptibility



Low Temp - RH ramping  
(medium conc.)



High Temp - RH ramping  
(medium conc.)

# Discussion

- **Accuracy:** Overall, the three IQAir AirVisual Pro sensors showed low accuracy, compared to the FEM GRIMM for PM<sub>2.5</sub>. IQAir AirVisual Pro sensors overestimated FEM GRIMM PM<sub>2.5</sub> readings in the laboratory experiments.
- **Precision:** The IQAir AirVisual Pro sensors showed high precision for all test combinations (PM<sub>2.5</sub> concentrations, T and RH).
- **Intra-model variability:** Low intra-model variability was observed among the IQAir AirVisual Pro sensors.
- **Data Recovery:** Data recovery for PM<sub>2.5</sub> mass concentration was 100% for all units tested.
- **Linear correlation:** The three IQAir AirVisual Pro sensors showed very good correlation/linear response with the corresponding FEM GRIMM PM<sub>2.5</sub> measurement data ( $R^2 > 0.99$ ) for mass concentration range between 0 and 250  $\mu\text{g}/\text{m}^3$ .
- **Climate susceptibility:** For all temperature and relative humidity combinations, the climate conditions had minimal effect on the IQAir AirVisual Pro's precision. IQAir AirVisual Pro exhibited huge spikes at the set-points of RH changes at low temperature (5°C) for all PM concentrations, smaller or no spikes were observed at higher temperatures.